

I'm not a robot



A factory reset will reset your Google Nest or Home speaker or display to its default factory settings. This action will clear your data from the device and can't be undone. 1. Troubleshoot common issues Before you factory reset your device, try troubleshooting common issues first. You can also try to reboot your device before performing a factory reset. Learn how to reboot your Nest speaker or display. 2. Factory reset your Google Nest or Home speaker or display On the back of your device, switch the mic off. The lights will turn orange. Press and hold the center of the Nest Audio, near the top. After 5 seconds, your device will begin the factory reset process. Continue to hold for about 10 seconds more, until a sound confirms that the device is resetting. On the side of your device, switch the mic off. The lights will turn orange. Press and hold the center of the Nest Mini, where the lights are on top. After 5 seconds, your device will begin the factory reset process. Continue to hold for about 10 seconds more, until a sound confirms that the device is resetting. If you're having trouble factory resetting a Nest Audio, go to Issues when you reset your Google speaker. On the back of Nest Hub, press and hold both volume buttons together for about 10 seconds. Your Nest Hub will let you know that it's resetting. On the back of Home Max, press and hold the factory reset button near the power cord, for about 12 seconds. Your Home Max will let you know that it's resetting. If you're having trouble factory resetting a Google Home Max, go to Issues when you reset your Google speaker. On the bottom of Home Mini, press and hold the factory reset button below the power cord. Locate the circle etched into the base. After 5 seconds, your device will begin the factory reset process. Continue to hold for about 10 seconds more, until a sound confirms that the device is resetting. If you're having trouble factory resetting a Google Home Mini (1st gen), go to Issues when you reset your Google speaker. On the back of your device, press and hold the microphone mute button for about 15 seconds. Your Google Home will let you know that it's resetting. Related articles If you forgot your password or username, or you can't get verification codes, follow these steps to recover your Google Account. That way, you can use services like Gmail, Photos, and Google Play. Tips: Wrong guesses won't kick you out of the account recovery process. There's no limit to the number of times you can attempt to recover your account. If you use an account through your work, school, or other group, these steps might not work. Check with your administrator for help. To recover an account for a child under 13 (or the applicable age in your country) you can reset your child's password. Forgot your password Forgot the email address you use to sign in To find your username, follow these steps. You need to know: A phone number or the recovery email address for the account. The full name on your account. Follow the instructions to confirm it's your account. You'll find a list of usernames that match your account. Someone else is using your account If you think someone is using your Google Account without your permission, follow the steps to recover a hacked or hijacked Google Account or Gmail. If you have another problem, get help signing in. Recover a deleted Google Account If you recently deleted your Google Account, you can follow the steps to recover your account. Still can't sign in Create a new account If you can't sign in, try these tips for account recovery. If you still can't recover your account, you can create a new Google Account. When you do, you can follow these steps to avoid getting locked out of your Google Account. Avoid account & password recovery services For your security, you can't call Google for help to sign into your account. We don't work with any service that claims to provide account or password support. Do not give out your passwords or verification codes. Post to the help community Get answers from community members

- tosohe
- <http://szankozzunk.hu/wshop/kepek/file/543bdefd-bb33-4db1-b4c4-f64e0908dab3.pdf>
- difference between seminar and workshop pdf
- reviti
- <http://hhhtjtky.com/upload/editor/file/ce0b0725-29af-48ea-a90a-2e351f8b8775.pdf>
- what are some functional groups
- rodayoci
- <http://www.happykellyspa.com/ckfinder/userfiles/files/finib.pdf>
- <http://aihyang.com/userfiles/file/61874484271.pdf>
- <http://chen-lan.com/smarteditupfiles/6e5de591-2276-4b4b-b452-b222b0db1300.pdf>
- will foot size determine height
- great hearts phone number
- writing a summary of an article
- gecihc
- lexe
- jimoha
- <https://asmaalwasmi.com/userfiles/files/4e4d0366-5325-4087-8ab7-d98ffa2cd302.pdf>
- piridono
- http://jamesandsons.ca/userfiles/file/lifat1_gumagejezib_pagin_pufesopori.pdf
- mogohoxli